

Replacing Control Panel On Model GQB

The following steps represent the process by which the older control system is removed and replaced with the enhanced push-button control system.

1. Disconnect power from the mixer.
2. Open mixer door.
3. Remove the four (4) screws at the top and bottom of the control panel and save for later use. (Figure 2)
4. Lift the control panel away from the mixer enough to expose the wiring.
5. Unplug the wire Harness connector from the white, square 9-pin connector. This will free the control panel from the mixer. (Figure 3)
6. Discard Older control panel.
7. Hold the replacement control panel over the opening and plug the wire harness connector into the white 9-pin connector.
8. Locate the replacement control panel over the four (4) holes and secure with the screws removed earlier.