

Replacing a Shock on 5G Shaker

For this job you will need a 1/4 inch nut driver, if you have a cordless it makes the job much easier because you have to remove about 19 screws to get the top and rear cover off the machine , once you remove them there are 2 shocks on each side, we believe one or more shocks popped out and that is why machine insides are crooked, if you have a 2x4 about 3 foot long you can use it to lift the inside of machine and sit on it while positioning the top portion of the shock to fit inside the bottom part a spring goes between the top and bottom part as you lift yourself up a little of the 2x4 you have both hands free to guide the shocks, just a suggestion having done this job many times in the past